

Cornelius - Viper Dispensers

Equipment Preparation Checklist



WARNING: To reduce the risk of injury, always unplug your Cornelius equipment before cleaning and performing preventative maintenance. Do not use metal scrapers, sharp objects or abrasives as damage may result to surfaces. Do not use solvents or other unapproved cleaning agents as they may harm plastic materials. Remember to use all appropriate Personal Protective Equipment (PPE) when cleaning and sanitizing.

Daily Maintenance	
	CAUTION: Do not use chlorine-based solutions on stainless steel surfaces.
	Clean all external surfaces with a mild soap solution and rinse with clean water. Dry all external surfaces with a clean soft cloth.
	Remove drip tray (if applicable) and wash with a mild soap solution.
	Dry tray thoroughly and replace it.

Monthly Maintenance	
	The air filter should be cleaned at least once a month.
	Open merchandiser.
	Remove filter by grasping the two tabs and sliding it straight out the front of unit.
	Carefully wash filter with clean water. Shake out excess water and wait for it to fully dry.
	Reinstall the air filter and close the merchandiser.

Sanitizing	
	The Viper system should be sanitized every 180 days. If you are nearing that time or want to sanitize in anticipation of greater usage, contact a qualified service technician.
	<i>Sanitizing should only be performed by qualified service technicians. Please contact your local service provider to schedule service.</i>

These instructions are written and meant for you or your staff to perform. For additional assistance performing this maintenance, please refer to your user manual or contact your local service provider.